

Instructions: Installation of a Wall Anchor

1. Position the wall anchor at the desired location on the wall and mark out holes with a pencil. We recommend installing the anchor at a height of 500mm measured from the bottom of the anchor to the ground.

If installed on brick work, position the anchor so that the bolt holes can be drilled in the middle of the brick, not in the mortar.

2. Drill 4 x 10mm holes deep enough to fit the fixings.

3. Take fixings apart then attach and reassemble all four to the back of the anchor. Make sure you do not tighten the fixings as it will cause them to expand.

4. Place the anchor with the fixings into the holes, making sure the bicycle logo is oriented the right way up. Tap the fixings gently until the anchor is flush against the wall.

5. Use the hex key to tighten up the fixings to secure the anchor.

6. If you require Wall Anchor to be permanently installed, hammer the ball bearings into the hex socket of the fixings.

Note: the fixings can no longer be undone. To remove, use an angle grinder to cut the ball bearing out so that the hex socket can be accessed.



Parts included:

- Cyclehoop Wall Anchor HD
- Sleeve anchors x 4
- Ball bearings x 4

Tools required:

- Electric drill with 10mm drill bit
- Pencil
- 5mm Hex key
- Hammer